





## OPERATING INSTRUCTIONS SAUNA TYLÖ SENSE SPORT 2/4

### Enjoy a little time out in your own sauna and please observe the following instructions.

- Before switching on, please check that there are no flammable objects on or near the sauna heater.
- Never allow children to play near the sauna.
- Never put fragrance concentrates directly on the hot sauna stones (fragrance concentrates and similar products can ignite if they are poured into the stone chamber undiluted).
- There is a risk of burns when touching the heater.
- Persons in poor health are advised not to use the sauna.
- Please only pour a small amount of water.

### Temperature settings

The thermostat switch shows an increasing heat scale. Find the sauna temperature that is most comfortable for you (usually 60 - 90 °C). You can leave the temperature setting at this level.




### Time settings

To set the time for an immediate start: turn the rotary switch past the first 3 hours and then back to the desired start time (1, 2 or 3 hours). The timer stops automatically at 0. To set the time for an automatic start: turn the rotary switch to 9 hrs and then back to the desired time preset (= the time when the heating switches on automatically).

The timer stops automatically at 0. You can turn the rotary switch forwards and backwards at any time, for example to stop the heating manually (turn to position 0), or to change the previous setting.

To create a pleasant fragrance in the sauna, drizzle a little sauna fragrance concentrate\*\* into the water of the fragrance concentrate container (number 1). Alternatively, you can drizzle a little sauna fragrance concentrate\*\* into the water of a sauna bucket and pour the water onto the hot stones. Use a sauna ladle to pour the water onto the hot stones.



**\*\*You can get this from us in the service office. We have the scents lemon, eucalyptus and cedar.**